Symbols

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

9	Replace the part (s) with new one (s) before assembly.
S TOOL	Use special tool.
0.P. TOOL	Use optional tool. These tools are obtained as you order parts.
10 (1.0, 7)	Torque specification. 10 N·m (1.0 kg-m, 7 lb-ft)
7	Use recommended engine oil, unless otherwise specified.
	Use molybdenum oil solution (mixture of the engine oil and molybdenum grease with the ratio 1 : 1).
GREASE	Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent).
- F WH	Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote® BR-2 plus manufactured by Dow Corning, U. S. A. Multi-purpose M-2 manufactured by Mitsubishi Oil Japan
-FOMPH	Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote® G-n Paste manufactured by Dow Corning, U. S. A. Honda Moly 60 (U. S. A. only) Rocol ASP manufactured by Rocol Limited, U. K. Rocol Paste manufactured by Sumico Lubricant, Japan
	Use silicone grease.
LOCK	Apply a locking agent. Use the agent of the middle strength, unless otherwise specified.
SEAL O	Apply sealant.
BBAAS S.U.D	Use brake fluid DOT 4. Use the recommended brake fluid, unless otherwise specified.
FORK	Use Fork or Suspension Fluid.