

Quick Reference Guide

General Information	1	■
Periodic Maintenance	2	■
Fuel System	3	■
Cooling System	4	■
Engine Top End	5	■
Converter System	6	■
Recoil Starter	7	■
Engine Lubrication System	8	■
Engine Removal/Installation	9	■
Crankshaft/Transmission	10	■
Wheels/Tires	11	■
Final Drive	12	■
Brakes	13	■
Suspension	14	■
Steering	15	■
Frame	16	■
Electrical System	17	■
Appendix	18	■

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.