VEHICLE IDENTIFICATION

Model Identification

The machine model number must be used with any correspondence regarding warranty or service.


Machine Model Number Identification A 0 8 LH 27 A A Year Designation Basic Chassis Year Designation

Engine Designation

Engine Designation Number

Designation

Vehicle Identification Number (VIN)





Vehicle and Engine Serial Number Locations

Whenever corresponding about a Polaris ATV, be sure to refer to the vehicle identification number (VIN) and the engine serial number.

The VIN can be found stamped on the lower frame rail on the front LH side of the ATV (see Figure 1-1).

The engine serial number is stamped on the center top of the crankcase beneath the cylinder and is also located on the sticker applied to the recoil housing on the right side of engine (see Figure 1-2).





1.2

Download this Manual http://ReadManuals.com