



Contents

Recommended Tools	2
Preparing to Work Inside Your Computer	2
Screw Identification and Tightening	3
ZIF Connectors	5
Removing Field-Replaceable Parts and Assemblies	6
Hard-Disk Drive Assembly	7
Memory Module Cover	7
Bottom Memory Module	8
Top Memory Module	9
Display Assembly	11
Display-Assembly Bezel	13
Display-Assembly Latch	15
LCD Panel	15
Replacing a Sharp LCD panel with a Sharp LCD panel or Replacing a Samsung LCD panel with a Samsung LCD panel	15
Replacing a Sharp LCD Panel with a Samsung LCD Panel or Replacing a Samsung LCD Panel with a Sharp LCD Panel	16
Removing the Packing Bezel on a New Sharp LCD Panel	17
Packing a Defective Sharp LCD Panel for Return Shipping	17
Keyboard Assembly	18
Palmrest Assembly	19
Bottom Assembly	22
Reserve Battery	22
Main Battery	23
Main Battery Release Latch	23
Thermal Cooling Solution	24
System Board Assembly	26
Touch Pad	29
Fan Assembly	29

Index

Figures

Figure 1. Computer Orientation	1
Figure 2. Main Battery Assembly Removal	3