

SERVICE MANUAL OUTLINE

SECTION 1 - General Information

SECTION 2 - Lower Unit (All Models)

PART A - Propeller

PART B - Gear Housing

PART C - Motor Assembly

SECTION 3 - "TM" (Transom Mount) Model

SECTION 4 - "RC" (Remote Control) Model

SECTION 5 - Electrical and Troubleshooting